

BALL TRANSFER TABLE

The Ball Transfer Table is used when products are required to be manually rotated or correctly positioned, such as a work station or other similar operation that requires quick, easy handling of the product. Ball Transfer Table is also used when more than two conveyor lines converge and packages must be transferred from one line to another.

- 1 in. Ball Casters
- Steel Channel Frame 3 ½ in. x 1 ½ in. x 10 ga.,
2 ½ in. x 1 in. x 12 ga. (Specify skate wheel or 138 Roller Type when mounted in 2 ½ in. channel)



Ball Caster Centers	Between Rail Widths (Weight Per Foot)														
	*10"	13"	15"	*16"	17"	19"	21"	22"	23"	25"	27"	31"	33"	37"	39"
2"	19.77	25.86	29.15	29.60	32.45	35.72	39.28	41.77	42.27	45.52	48.81	55.35	58.65	65.19	68.48
3"	15.09	18.06	20.57	21.02	21.53	23.99	25.50	26.95	27.45	29.92	32.43	35.85	38.37	41.79	44.30
4"	12.75	15.33	17.45	17.90	18.41	20.48	21.43	21.80	23.55	24.46	26.58	29.61	30.57	33.60	35.72
6"	-	-	-	15.56	16.07	16.97	18.70	19.15	19.665	20.56	22.90	24.15	25.86	27.75	29.48

